



T Transfer Point

Blue to Orange Connector Needed

7 1/2 Minutes

10 Minutes

Peak Period Only Clockwise Loop (5 - 10 Minutes)

7 1/2 Minutes